

TUB0x quick setup

TUB0x quick setup guide for supported box mods:

1. Download and install the latest tubomyevic firmware onto your compatible box mod, see the tab firmware on www.lamart.ch for instructions
2. Enter the coil resistance value for your device in 'menu>coils>manage' at the line TCR, make sure the lock symbol is after the number. Set Check to 'NO'
3. Confirm that in 'menu>coils>TCR' values M1-3 are set to 185
4. Connect your TUB0x via the 510 screw connection of your box mod
5. Select Temperature, triple click the fire button to use warmup mode, double click the fire button to use cruise mode (session) or press and hold the fire button to use on-demand mode

TUB0x quick setup guide for unsupported TC box mods:

1. Connect your TUB0x while cold to your box mod via the 510 screw connection when the unit is completely cold
2. Lock resistance (ohms) on your box mod, see model specific manual for instructions
3. Set TCR value to 185, see model specific manual for instructions
4. Select Temperature, press and hold the fire button to use the device on-demand

TUB0x quick setup guide for power/wattage mode:

1. Connect your TUB0x to your box mod via the 510 screw connection
2. Select Watts (20-50W), press and hold the fire button to use the device on-demand